EMERGENCY EQUIPMENT ISSUES? Dial 214-768-8888

Using Your Classroom Equipment

If the touch panel display is off, tap the screen to turn it on.

1. Select the desired **Source**
   a. If "input not detected" is displayed, verify the lectern computer is powered on or that the HDMI or VGA cable is plugged securely into your laptop/device.
2. Select the **Projector** display
3. If you selected a laptop as your source, you may need to change settings to duplicate your screen. This can be done by pressing **Win+P** on a PC, or by changing your Mac's display settings in System Preferences.
4. **Volume**
   a. Tap the Volume up down buttons on the right side of the touch panel
   b. Adjust the computer volume as needed
   c. Mute using the audio icons
5. **Blank Screen**
   a. Tap the **Blank Screen Button** below the projector
   b. Tap the **Blank Screen Button** again to restore the image
6. **Other devices**: press and hold the designated input button for three seconds. A special page for Blu Ray or Document Camera will appear.

For more information, visit smu.edu/classroomtech